More bars, faster websites.

Before you start up, please make sure that you have:

- a fixed broadband modem or modem/router
- your Vodafone 3G phone or device
- 3 a nearby mains power socket.


How the Vodafone Sure Signal works

The Sure Signal contains a small 3G rne sure signat contains a small 56 transmitter and receiver, which it uses to connect with registered 3G phones, laptops with internal 3G modems, and USB 3G modem sticks, rather like a Wi-Fi network does.

It then relays calls, emails and internet access through your existing broadbanconnection.

You will get the best results if you position your Sure Signal as centrally as possible, and avoid putting it too close to metal objects or other transmitters (like Wi-Fi routers).





Quick setup

- 1 plug the supplied yellow Ethernet cable into the yellow Ethernet port (connector) labelled ROUTER/MODEM on your Sure Signal
- plug the other end of the yellow cable into to a spare Ethernet port on your broadband router/modem*
- plug your Sure Signal into the mains power supply you will see the front red Power light turn on.

Automatic configuration

Your Sure Signal will now start its configuration process. This is fully automated and may take up to an hour to complete.

- first, the System a and Phone by lights will flash. When the Sure Signal has established an internet connection with Vodaf the Phone light will go out this may take up to 10 minutes.
- the System (i) light will carry on flashing, then the Phone (i) light will briefly flash again, while the rest of the configuration is completed.
- when the System 🖟 light stays lit you should now have full 3G signal strength on your phone or a fast internet connection on a USB modern

Once it's set up we recommend that you leave it plugged in at all times to maintain service and optimise performance.

If the configuration doesn't complete

- if the Phone () light hasn't gone out after the first 10 minutes: this indicates that although a connection has been made with Vodafone, y Sure Signal may not be activated. Please note that it may take up to 3 days to activate your account.
- if both the Phone (\blacksquare) and System (\blacksquare) lights are off after the first 10 minutes; this means the Sure Signal can't connect to Vodafone. Check your Broadband connection and firewall settings.
- the Sure Signal will automatically restart the configuration process after another 5 minutes.

FAQs

How do I check that my mobile is using the Vodafone Sure Signal?

The Phone light () on the Sure Signal will be on while your phone is in

Why won't my phone connect to the Vodafone Sure Signal?

The Sure Signal supplies a 3G signal If your phone is a 3G phone, please check it is set to use the 3G service.

Check whether the maximum number of simultaneous users (4) has been reached.

If I leave my Vodafone Sure Signal plugged in all the time, how much electricity will it use?

The Sure Signal uses about the same power as a typical Wi-Fi router.

What are the radio frequency emissions from the Vodafone Sure Signal?

The power light | keeps flashing. What does this mean?

The Sure Signal has a fault. Please contact Vodafone.

The System light is not staying lit

Please check that all the cables are plugged in securely.

Also, check whether your broadb connection is working properly.

Since I plugged my Vodafone Sure Signal in I have been unable to connect my PC to the internet via Wi-Fi. Is there a fault?

No, but if the Sure Signal is situated too close to your Wi-Fi router this can occasionally affect the range of the Wi-Fi.

To rectify this please move your Sure Signal further away from your router (there is no need to move it further than the supplied cable allows).

Go to vodafone.ie/suresignal



What do the lights mean?



Power On - the Sure Signal is powered on Rashing – the Sure Signal has a fault: please check your broadband connection before contacting Vodafone

System Off – the Sure Signal can't provide a service On – the Sure Signal is ready for use Flashing – the Sure Signal is being configured

Off - no calls or internet connections

Off — no caus or internet connections being made On — one or more calls or internet connections in progress Flashing — the maximum number of simultaneous users has been reached (Sure

Signal can handle up to 4)
Flashing at the same time as the System light – the Sure Signal is being configured Flashing while the System light is off – the system is working, but network issues may affect your service